


SPOK₂₁

Reset of the device settings

The following informations refer to the software-version V2.0r03 and higher.

The different settings of the device (to change with  + Enter) are stored in a certain component. To reset this with the default values use the procedure like this:

1. Switch the device off
2. Press the 3 keys simultaneous (see the picture below)
left side of the display: upper and lower key
right side of the display: middle key.
The device will switch on.
3. Release the keys when text appear on the screen.

If the software is malfunctioned and SPOK couldn't switch off with the appropriate keys, do like this:

1. Switch off with the battery-switch at the bottom.
2. Press the 3 keys simultaneous (see the picture below)
left side of the display: upper and lower key
right side of the display: middle key.
While pressing the keys plug in the charger in the charger plug.
4. Release the keys when text appear on the screen.

Possible choice:

There are 3 possibilitys shown on the display:

Reset settings	➔	Reset of the device settings (not the the settings of the scanning modul)
Reset user texts	➔	Delete all user texts and/or set texts to default (if there are defaults)
Start normal	➔	Continue to normal start



SPOK21