

**SPOK<sub>21</sub>**

## Assembly Instruction for the carrying handle

Scope of delivery:

1. carrying handle (1 pcs)
2. thread bolt with hole (2 pcs)
3. key ring 18mm Ø (2 pcs)
4. cranked wrench key Torx T20 (1 pcs)
5. instruction (1 pcs)

2 screws of the SPOK case will be changed with the thread bolts.  
The 2 key rings were assembled to the holes of thread bolts.

**In order that the case of SPOK is not opened, please change the screws consecutively with the bolts.**

1. Mount the key rings to the thread bolts
2. Dismount the first screw with the provided cranked wrench key.
3. Mount the first thread bolt.
4. Same with the second screw / bolt.
5. Mount the carrying handle through the key rings.

