

SPDK21

Assembly Instruction Keyboard

The keyboard is fixed with 4 screws (M3 (metric 3mm)) on the device.

How to change the keyboard:

1. Switch off the device with the transportation-lock switch at the bottom.
2. Remove the 4 screws. 1 + 2 = 12mm , 3 + 4 = 10mm .
3. Turn the device and remove the keyboard.
4. Check the proper alignment of the 13 connectorpins of the connector.
5. Check the proper position of the O-ring around the connector.
6. Place the new keyboard. Orientation is the upper edge of the keyboard.
7. Turn the device and put it on a plane surface.
8. Fix the 4 screws. Attention to the correct lenght.
9. Don't fix the screws too hard!.
10. Switch on the transportation-lock switch at the bottom.

