

# SPOK<sub>21</sub>

## Assembly Instruction for the keyguard

Scope of delivery:

1. Keyguard ( 1 pcs)
2. Screws M3x 20mm with washer ( 2 pcs)
3. instruction (1 pcs)
4. cranked wrench key Torx T10 (1 pcs)

The keyguard will be fixed with 2 screws at SPOK

How to mount the keyguard:

1. Switch off the battery switch.
2. Dismount the 2 screws 1 + 2 (M3, 12mm ).
3. Remove the protection film from the keyguard.
4. Slide the keyguard over the keyboard.
5. Turn SPOK and fix the keyguard together with the keyboard with the delivered screws M3 x 20mm. The 2 screws are longer than the one you removed..
6. Fix the screws moderate.
7. Switch on the battery switch.

